

## Packaging of tissues

The cartoning machine that is economical due to its high degree of availability.



The example of the packaging of cosmetic wipes documents the product-compliant and practice-compliant coordination of the BK cartoning machines to the packaging tasks in question.

- Gentle handling of the sensitive tissue stack
- Direct linkage to a continuous manufacturing machine
- Roller conveyor for abrasion-free product accumulation
- Automatic outfeed if there is a product accumulation
- Reliable transfer to the pocket chain with automatic positioning
- Processing of stacks that are higher than the folding cartons

- Option for manual product loading
- Dependable product insertion due to product guidance on all sides
- Leading pre-inserter for the inside window at the carton base end
- Walking beam for insertion, with lowering movement for product compression
- Large, foldable work table

### Technical data

**Output** up to 80 cartons / minute



Two feeds for normal and folded (boutique) tissues for the highest degree of efficiency



On-line sorting of cartons with varying colors and imprints



Gluing and subsequent closing of cartons